

Release notes for software version v02.03

CEECOACH 1 and CEECOACH 2 can be used in one communication circle when all devices have software **version 02.01** at least. Anyway, we recommend to use the latest version for all your devices.

CEECOACH 1 can still **be used only** with a **wired headset** (no Bluetooth headset). In addition, **CEECOACH 2** can be used **with Bluetooth headsets**. When using a Bluetooth headset, no audio output is played on the cable headset.

Improved performance/Bugfix:

- CEECOACH can now be used while being connected to power supply (e.g. power bank).
- Updated to v02.03 CEECOACH 2 is charging significantly faster.
- Better echo cancelling for wired headsets
All devices have to be updated, as the echo is produced by the counterpart
- Optimized announcement for battery status
- Adjustments for connection with various additional Bluetooth headsets

Furthermore, the overall performance of the device has been improved.

Bluetooth pairing with smartphone and/or headset:

Activate pairing mode on CEECOACH by pressing plus (+) and minus (-) buttons simultaneously until CEECOACH is rapidly blinking yellow.

Pair a smartphone:

Activate pairing mode on CEECOACH.

Turn on Bluetooth on your smartphone and start searching for Bluetooth devices. CEECOACH is displayed as "CEECOACHxxxx" including the last four digits of the serial number, found on the back side of the device. Select your CEECOACH to establish a connection.

Pair a Bluetooth headset:

Turn on your headset and put it into pairing mode (if applicable, please read the headset manual).

Activate pairing mode on CEECOACH 2. CEECOACH 2 is now searching for a headset (approx. 60 seconds).

Note: CEECOACH 2 is only searching for a headset when no other headset is currently connected. If you would like to connect another headset, please first turn the connected headset off.

After successful pairing of either a smartphone or a headset, CEECOACH 2 will leave pairing mode. If you would like to connect both, a smartphone and a headset, please repeat the pairing procedure.

Controlling CEECOACH 2 via headset button:

Most Bluetooth headsets have a button (if applicable, please read the headset manual), that can be used to control the connected CEECOACH 2.

You can use the button for the following actions:

- Activate and deactivate the participant mode.
- Accept an incoming call or terminate an active call.

Larger distances or obstacles between Bluetooth headset and CEECOACH 2 may cause audio distortions. For the best audio quality, wear your CEECOACH 2 and your headset on the same side of your body.